

“Goldfinger” Honey Wheat

Malt Base 4 lb. Dry Wheat Malt Extract **OR** 5 lbs LME, 1 lbs. Honey

Specialty Grains: 1/2 lb. Flaked Wheat, 1/2 lb. Flaked Barley, 1lb Honey Malt

Hops: 3 HBU Hallertau Hop Pellets (Bittering)

Other: 2 Muslin Bags, Bottle Caps, Priming Sugar

Suggested Yeast: White Labs American Hefewiezen 320

Instructions:

1. Remove **Grains, Flaked Wheat and Flaked Barley** from package and put in muslin bag. Tie bag at end to allow maximum circulation. Place in **minimum** 2 gallons cold water, slowly bring to approx. 160 deg., hold temp for 10 min. Discard grain.
2. Add **Dry Malt Extract**, stir well to dissolve. Bring to a boil, add **Hops**, and continue boil for 45 min. Add **Honey** and boil for 15 min. more.
3. Pour unfermented beer (wort) slowly into fermentation vessel containing enough cold water to total 5 gallons.
4. Let temperature drop to approx. 80 degrees. Take hydrometer reading, sprinkle or “pitch” yeast on top. Affix cover and airlock to fermenter and stabilize temp. at approx. 67 – 72 degrees.
5. Airlock should be active within 24 hours, with fermentation slowing down by the end of day 7, the clearing stage is beginning. Siphon beer into clean carboy, affix airlock and cover to keep light out and let clear for approx. 7 days.
6. When ready to bottle, boil priming sugar in approx. 1 cup water for 1 minute, add to bottom of bottling bucket, then siphon beer into the same bucket (take final hydrometer reading while siphoning into bucket). Fill bottles to 1 “ from top of bottle and cap.
7. Store beer at 67 – 70 degrees for 7 – 10 days minimum.

Starting Gravity: 1.045

F.G: 1.012